

How To Set Up Your Shadeling



Open up the bag! The kit will come with:

- 1 X Shadeling (approx 3m x 3m)
- 2 X Collapsible 2.2m aluminium poles (3 sections) with pole socks
- BONUS 2 X Collapsible 1.4m aluminium poles (3 sections) with pole sock
- 4 X Stainless steel pegs in a bag
- 4 X High Vis tie down ropes (already attached)

1



Lay the Shadeling out flat on the ground, stitching down

Take into consideration the position of the sun and the path it will take

2



Start at any corner and pull the rope out to the end, hammer in the peg
Go to the opposite corner and do the same

Do NOT pull the ropes hard and stretch the Shadeling.
Just have everything lying flat and straight with no tension.

3



Peg out the remaining ropes/corners

Open up the poles

4



Lift the Shadeling, inserting the squishy ball end of the pole into the corner

Avoid putting the ball directly onto the stitching, aim for fabric only



5



Repeat with the second pole in the other corner
Adjust the poles accordingly

Time to chill under your Shadeling!

6



Limited room to set up?

You can tie a loop in the back ropes closer to the corner and peg from there!

This also lessens the trip hazard, and will make the Shadeling more sturdy in wind

Add the smaller poles to the back corners for extra space

7



heavy wind causing the Shadeling to fly up and the poles to fall out?
Use the pole socks and tie them around the squishy balls!
If the wind is extreme, **take the Shadeling down** to prevent it getting broken or damaged and injuring you or others.

Check the website for the instructional set up video
www.alchemydecor.com.au/set-up

Packing Down Your Shadeling

1



Take out all poles and pegs, then fold the Shadeling in half

4



Fold in thirds again

7



Wrap with ropes

2



Fold in half again

5



Put pegs and poles on against one side

8



Put back into carry bag

3



Now in thirds

6



Roll everything up to the other end